

Installing PVC Capitals and Bases on Fiberglass Columns

We recommend that the mounting Brackets be placed at opposite sides from each other.

All four sides of the bases are notched on the inside although only two brackets are required.

Glue in place using construction adhesive, hold in place with tape until the adhesives cures.

Note: Do not use PVC adhesive as it will only bond PVC to PVC not to the fiberglass column shaft.

